

Click to verify



























×Sorry to interruptCSS Error ×Sorry to interruptCSS Error ×Sorry to interruptCSS Error There are many reasons why people love the Kogan TV. Besides from coming at an affordable price, the device offers decent images on its screen. Moreover, various settings can be used to make them clearer. Finding the ideal picture settings might be time-consuming. But if you use this guide, you can adjust the quality of your television within minutes. Now let's dive in and discover the parameters for tuning the Kogan TV. Here are the settings for adjusting the images on the Kogan Smart TV. But before using our suggestions, go through the owner's manual of your device. For the Kogan 55" Smart HDR 4K LED TV If you want to watch your favorite TV program on this TV, try the following settings: Set Contrast to 50: As you set up the Kogan TV, keep the contrast at 50. With this setting, you should view every detail at the brightest parts of the screen. Adjust Brightness to 52: If you want to get the best picture on your Kogan TV, make the Brightness stay at 52. At this level, the screen stays balanced without looking dim or too bright. Set Color to 68: Before you have a perfect picture on Kogan TV, you should aim for realistic color tones. To achieve this goal, keep the Color to 68 Leave the Sharpness at 18: If you don't apply the right Sharpness settings, your movie scenes will appear muddy. However, you can avoid this issue by adjusting the Sharpness to 18. Reduce the Tint to 0: As you adjust the picture setting on the Kogan TV, do not skip the Tint setting. For the best results, keep the Tint at 0 Adjust the Backlight to 75: By setting the Backlight, you can control the amount of light produced by the Kogan TV. As you are aiming for a perfect display, leave the Backlight at 75. Set the Temperature to Medium: Round up your picture settings by leaving the Temperature on Medium. Then use the following parameters: R Gain: 943, G-Gain: 994, B Offset: 930, R Offset: 1020, B-Gain: 849, G Offset: 1024 N.B To get to the Temperature setting, press the Menu key on the remote. Then press type 2008 and go to the WB Adjust menu. How to Adjust Brightness on Kogan TV? Are confused about the best way to tune the Brightness setting of your Kogan TV? If yes, here are some quick steps to help with the job. Press the Menu button on the remote. Scroll downwards to Picture Press the Right Key Scroll downwards to Brightness Use the Left or Right key to adjust the brightness levels. Is Kogan an Android TV? Yes, Kogan has a wide selection of Android TVs. However, the brand also has traditional LED TVs without the smart features. Is Kogan TV Good? Yes, Kogan offers different sizes of TVs with decent features. Besides, these devices come at affordable prices. Why is My Kogan TV Blurry? If your Kogan TV becomes blurry, then you might have used the wrong picture settings or a faulty HDMI cable. Besides, inserting the latter wrongly can also cause the same problem. How Do I Change My HDMI Settings on My Kogan TV? You can quickly change your HDMI settings by using the following steps: Get the Kogan TV remote Press the Settings button Navigate the cursor to HDMI EDID Mode Select HDMI 2.0 Exit the menu How Do I Set Up My Kogan TV Without a Remote? Have you lost your Kogan Smart TV remote? If yes, then you can still operate the TV by using the Android TV Remote Control app with a Bluetooth or Wireless Connection. To use the application with a Bluetooth Connection: Visit the Google Play Store on your smartphone. Type "Android TV Remote Control" into the Search bar Download and install the app Turn on the Bluetooth function on your smartphone. Enable "Discoverable Mode" under the Bluetooth setting of your device Turn off the Wifi connection on your TV Scroll to the Remote & Accessories tab on the TV Scroll through the list and select your smartphone from the list Launch the Android TV Remote Control app from your smartphone. Scroll through the list and select the Kogan TV from the list to complete the pairing process To use a Wireless connection: Download and install the Android TV Remote app on your smartphone. Connect the smartphone and TV to the same EFiNetwork. Launch the Android Remote Control app on your smartphone. Select the Kogan TV from the list of devices on your smartphone phone screen Type in the required code to complete the pairing process. ×Sorry to interruptCSS Error ×Sorry to interruptCSS Error ×Sorry to interruptCSS Error Kogan TVs have earned a reputation for their affordability and quality. However, did you know that these TVs hide a treasure trove of advanced settings within their Service Menu? In this guide, we'll take you through everything you need to know about accessing and using the Kogan TV Service Menu in 2023. The Service Menu is a hidden feature within your Kogan TV that provides access to advanced settings and configurations not available through the standard user interface. It's a powerful tool, but it should be used with caution as making incorrect adjustments can impact your TV's performance. You might wonder why anyone would venture into the Service Menu. Well, it can be a game-changer when you want to fine-tune your TV's display, audio, or troubleshoot issues. However, keep in mind that it's not for casual users and should be approached with care. Remote Control Combinations: Turn on your TV. On your remote, press the MENU button. Enter the code: 2, 0, 0, 8. Physical Buttons on the TV: If your remote isn't handy, you can often access the Service Menu using a combination of physical buttons on your TV. Check your TV's manual for specific instructions. If you're feeling adventurous, there are advanced methods like using USB firmware updates or external devices like a Raspberry Pi to access the Service Menu. However, these methods are riskier and may void your warranty, so proceed with caution. Once you're in the Service Menu, it's essential to understand how to navigate it effectively. The Service Menu typically has a hierarchical structure with various options and submenus. Use your remote or TV buttons to navigate through these menus. Use the arrow keys or buttons to move through the menu items. To select an option, press the OK or Enter button on your remote or TV. Be cautious and avoid making changes unless you know what you're doing. You can adjust settings like brightness, contrast, color calibration, sharpness, volume control, and equalizer settings from within the Service Menu. Just be sure to note down the default values before making any changes, so you can revert if needed. Most Service Menus allow you to save changes before exiting. Always save your settings to ensure they take effect. Here are some common adjustments you can make within the Service Menu: Brightness: Adjust the overall brightness of your TV. Contrast: Fine-tune the contrast to enhance image clarity. Color Calibration: Perfect your TV's color settings. Sharpness: Control image sharpness for a crisper view. Volume Control: Adjust the TV's volume levels. Equalizer Settings: Customize audio frequencies. Audio Test Tones: Fine-tune audio for optimal quality. Firmware Updates: Check for the latest firmware updates. Factory Reset: Reset your TV to its default settings. Calibration Options: Access advanced calibration tools. Error Codes: Decode error messages for quick fixes. Debugging Tools: Diagnose and resolve issues efficiently. Unlocking the Kogan TV Service Menu can be a rewarding experience if you're looking to enhance your TV's performance. However, always approach it with care, and remember that tinkering with advanced settings should be done responsibly. Your TV's warranty and performance are at stake! Explore the possibilities within your Kogan TV, but do so wisely.